

Running Board Instructions

2091

(04 – 09) Dodge Durango

(No Drilling Required)

INSTALLATION PACKAGE

Running Board	2
Brackets	6
Mounting Straps	6
Bolt Pack (Brackets)	1
Bolt Pack (Boards)	1

Necessary Tools

Ratchet wrench with 1/2" & 13 mm socket
Combination wrench
Safety glasses

Bolt Pack Brackets

5/16" x 3/4" Hex Bolt	18
5/16" x 3/4" Serrated Flange Nut	18
5/16" Washers	18
1/4" * 1 1/4" Hex Bolts	6
1/4" Flat Washer	6
1/2" Well Nut Rubber Grommet	6

Bolt Pack Running Boards

5/16" x 3/4" Hex Bolt	12
5/16" Serrated Flange Nut	12

STEP ONE : Determine proper bracket placement Fig A & B & C

1. There are (3) places on lower rocker panel where the brackets need to be placed. Locate the factory holes indicated in Fig A. Plastic strip may hide mounting holes and must be removed to install boards.
2. Insert well nuts in upper hex hole which may be covered by factory tape. Use 1/4" bolt and washer to install brackets. Fig B
3. Loosely bolt (hand tighten) brackets as shown in Fig D Install all brackets the same way.
4. Place board on brackets by sliding mounting bolts in slots on underside of boards and allow bolt thread to drop through bracket slots. With brackets mounted in position, slide 5/16" bolts down outside channels on underside of board so bolt studs will line up with bracket slots and install board on brackets. It is only necessary to use one bolt to hold board on each bracket if only one slot lines up.
5. Check board for levelness and snug fit to vehicle. Adjust up and down or in and out and fully tighten outside brackets first. Then adjust inside bracket accordingly. Fully tighten all brackets.

STEP TWO : Board Installation Check.

- 1) IMPORTANT: Check all bolts to verify completed mounting and tightness. Installation is complete

