

Running Board Instructions

3020

(2010 – C) Ford Transit Connect Van
(Drilling Required)

Installation Kit Parts

Running Board	2
Bracket s Front	2
Bracket s Middle	2
Brackets Rear	4
Bolt Plate 3.5" (Use On Middle & Front Brackets)	4
Bolt Plate 2" (Use On Rear Brackets)	4
Twist Straps	8
Bolt Packs For Boards & Brackets	2

Necessary Tools

Combination ratchet wrench set with 1/2" deep well socket
Variable speed drill w/ 3/8" hex head drive
Safety glasses

Bolt Pack Brackets

14 * 3/4" Self Tapping Screws	16
5/16" x 3/4" Hex Bolt	8
5/16" Serrated Flange Nut	16

Bolt Pack Running Boards

5/16" x 3/4" Hex Bolt	16
5/16" Serrated Flange Nut	16

STEP ONE : Determine proper bracket placement

1. Locate support rails on the underside of the van were the brackets need to be placed. Starting at the back near the leaf spring perch will be the first hole. Moving towards the front use the following. **Driver side use holes #1, #2, #4 and #5. Passenger side use holes #1, #4, #5 and #6.**
2. Place 2" bolt plates in rear smaller holes (2) each side - Fig A & B. Place 3.5" bolt plates in front large oval holes (2) each side – Fig C & D. Acquire brackets front, middle and rear use Fig G to help determine correct bracket. Mount each bracket as shown Fig G using installed bolt plate with 5/16" serrated flange nut hand tight, be sure to install top of bracket in second hole from tip as shown Fig E & F. Brackets in Fig F should be centered in oval hole. Attach a strap to each bracket using 5/16 bolt & nut Fig H & I.
3. Slide 5/16" * 3/4" bolts down outer channels on underside of boards, so (2) bolts are located at each bracket location. Place boards on brackets with bolts dropping through slots in brackets and secure with 5/16" serrated flange nut to board hand tight.
4. Fully tighten top of brackets to support rails on vehicle. Board at this point should be close to its final installed location. Center board on vehicle to your preference.
5. Now apply slight pressure up or down to make board level at each bracket location and use (2) self tapping tek screws to attach straps to inside rocker panel Fig H. Only (1) self tapping screw required for mounting rear strap to vehicle channel Fig I.

STEP TWO : Board Installation Check.

- 1) **IMPORTANT:** Check all bolts to verify completed mounting and tightness. Installation is complete

