

Running Board Instructions

4065

2001-2007 Toyota Sequoia
2004-2006 Toyota Tundra Double Cab

(No Drilling Required)

INSTALLATION PACKAGE

Running Board	2
Installation Instructions	1
Bracket	8
Bolt Pack	2

Necessary Tools

Ratchet wrench with 1/2" & 13 mm socket
Combination wrench
Safety glasses

Bracket Bolt Pack

8mm Hex Bolt	8
5/16" Flat washer	20
8mm Hex Nut	6

Running Board Bolt Pack

5/16" x 3/4" Hex Bolt	16
5/16" Flange Nut	16

STEP One: Determine proper bracket placement

- 1) There are 4 mounting locations on the rocker panel. Each location (except for the front) has 1 threaded hole and one threaded stud.
- 2) The front mounting location only has the threaded hole, no stud.

STEP Two: Loosely bolt brackets to vehicle

- 1) Bolt the brackets on by hand tightening the metric bolt into the threaded hole in the rocker panel.
- 2) Allow the threaded stud to come through the top slot of the bracket, hand tighten with the provided metric nut.
- 3) Place board on brackets with bracket mounted in position. Look on underside of board to which channel match up with bracket slots to slide 5/16" bolts down on underside of board so bolt stud will lined up with bracket slots. You will only need one bolt to secure board per bracket. Install board on brackets to see if board is level.
- 4) Hand tighten the board to the brackets using 5/16" flange nuts.
- 5) Slide board in or out to desired location & tighten down flange nuts under running board

STEP Three: Tighten brackets

- 1) Push board tight against vehicle and tighten bolts Fig C
- 2) Check that all brackets are tight before stepping on boards.

