



Sharp Boards LLC
840 NW 24th Court
Ocala, FL 34475
1-352-840-9696

SBR190
Chevrolet Equinox 2005 +

1. Mount two “L” straps on under body against cladding using tek screws, (Equally space 1st set of “L” straps from the second and third set of “L” straps.)
2. Fasten 3 hole end of bracket to frame using tek screws.
3. Mount boards and tighten all bolts and screws. (Do not over tighten tek screws)