

Running Board Instructions

7020

05-C Nissan Frontier King & Crew Cab
05-C Nissan Pathfinder (4 Door)

(No Drilling Required)

INSTALLATION PACKAGE

Running Board	2
Bracket s	6
Bolt Pack (Brackets)	1
Bolt Pack (Boards)	1

Necessary Tools

Ratchet wrench with 1/2" & 13 mm socket
Combination wrench
Safety glasses

Bolt Pack Brackets

8mm Flange Nuts	12
5/16" Washers	2

Bolt Pack Running Boards

5/16" x 3/4" Hex Bolt	12
5/16" x 3/4" Serrated Flange Nut	12

STEP ONE : Determine proper bracket placement Fig A & B & C

1. There are (3) places on lower rocker panel were the brackets need to be placed. Locate the factory studs indicated Fig A.
2. Loosely bolt (hand tighten) brackets as shown Fig A , B , C using supplied 8mm nuts install all brackets the same way. Front bracket will require 5/16 washer as spacer to keep board level. Install as shown Fig C
3. Place board on brackets by sliding mounting bolts in slots on underside of boards and allow bolt thread to drop through bracket slots with bracket mounted in position, slide 5/16" bolts down outside channels on underside of board so bolt stud will lined up with bracket slots & install board on brackets to see if board is level.
4. Check board for levelness and snug fit to vehicle. Adjust up and down or in and out and fully tighten outside brackets first then adjust inside bracket accordingly. Fully tighten all bracket.

STEP TWO : Board Installation Check.

- 1) Check all bolts to verify completed mounting and tightness. Installation is complete

