
Super Hoop Multi-Mount Step Installation Instructions


Part No's: 121241 / 121242 / 121244 / 121247



Vehicle Application:

Drill Motor, 5/16" drill bit, 1/8" drill bit, 2 - 1/2" wrench, 2 - 7/16" wrench, Phillips

2 – Super Hoop step castings, 4 – Large mounting brackets, 4 –, 2 – Hardware packs, 1 – Instruction. (Important! Not all of the parts in these hardware packs



Large mounting

bracket





WARNINGS!

- \checkmark Do not over tighten the nuts and bolts or damage to the castings and or stripping of the threads could result.
- ✓ FOR SAFE AND PROPER USAGE OF THIS PRODUCT, THE MOUNTING INSTRUCTIONS MUST BE FOLLOWED CAREFULLY AND COMPLETELY.
- The manufacturer and distributor of this product are in no way responsible for the consumer's failure to adhere to the warnings and directions of these instructions in the event of damage to the consumer's vehicle, other properties and or personal injury.
- 1. For the proper position of the step, the front edge of the seat while in normal driving position should be in line with the center of the step. For personal preference or to avoid any obstruction underneath body metal, step can be moved left or right.
- 2. Assemble the steel brackets to the step as shown in the Diagram A, and securely tighten.
- 3. When positioning the step against the body metal, be sure to avoid all bumps and screws to make sure that the step assembly is against a flat surface.
- 4. When the desired location is found, while holding the step in that position, take a short pencil and mark through the hole located in the front of each large mounting bracket onto the body metal.
- 5. Center punch the marked hole
- 6. Take a 1/8" drill bit and drill out the centered punched holes.
- 7. Replace the 1/8" drill bit and drill out the 1/8" hole for the marked 5/16" hole with a 5/16" drill bit.
- 8. After drilling, make sure that all the burrs are removed.
- 9. Place the large mounting brackets only back on the vehicle where the holes are drilled.
- 10. Take the 5/16" hardware that is provided and hand-tighten both large mounting brackets to the vehicle.
- 11. Take a 1/8" drill bit and drill two more holes through the square holes that are located on each large mounting bracket.
- 12. Take the sheet metal screws provided and securely tighten.
- 13. Place the step back into the large mounting brackets as shown in Diagram A and securely tighten all hardware.
- 14. Repeat all the above for the other side of your vehicle.
- 15. Make sure all hardware is securely tightened and that all the directions of this instruction have been followed carefully and completely, otherwise product failure could occur.

Carr Pattern Co., Inc. Warranty Policy
Finishes: Limited Lifetime Wallandy Foncy
Structural Warranty: Limited Lifetime
Warranty Conditions:
a. All warranties start from consumer's date of purchase.
b. A new product will be sent out immediately to replace a warranty claim.
c. The above guidelines apply only to the Original Parchaser.
d. Original proof of purchase must be submitted for all warranty and returns issues.
Warranty Limitations:
a. Warranty coverage extends ONLY to repair or replacement of the CARR product. This warranty does not cover the cost of labor, transportation, installation or removal of the product.
b. Warranty coverage does not extend to damage caused by: collision, fire, theft, freezing, vandalism, riot, explosion or object striking the product, or misuse of the product and/or the vehicle on
which the product is being installed.
c. Warranty coverage does not extend to damage caused by: airborne fallout (chemicals, tree sap, etc.), stones, hail, earthquake, water or flood, windstorm, lightning, the application of chemicals or
sealants subsequent to manufacture.
d. Warranty coverage does not extend to damages caused by: normal wear and tear, abuse, modification or improper installation of the product.
e. Warranty coverage does not extend to any economic loss or extra expense including (without limitation), payment for the loss of time or pay, inconvenience, storage, loss of vehicle use, vehicle
rental expense, equipment rental expense, lodging, meals, or other travel costs.
Other Terms:
This warranty gives you specific legal rights and you may also have other rights that vary from state to state. CARR does not authorize any person to create for it any other obligation or liability in connection with its products. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE APPLICABLE TO THIS PRODUCT IS LIMITED IN
DURATION TO THE DURATION OF THIS WRITTEN WARRANTY. PERFORMANCE OF REPAIRS AND NEEDED ADJUSTMENTS IS THE EXCULSIVE REMEDY UNDER THIS
WRITTEN WARRANTY OR ANY IMPLIED WARRANTY. CARR SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM BREACH OF
THIS WRITTEN WARRANTY.*
*Some states do not allow limitations on how long an implied warranty will last or the exclusion or limitation of incidental or consequential damages, so that above limitations or exclusions may not

apprive you. Guarantee: Every attempt has been made to manufacture and distribute the finest quality products available. Our manufactured products are guaranteed to be free of defects due to workmanship or materials. Distributed products are subject to manufacturer's warranty only.