



### Installation instructions ( p/n: 13235.30, 13235.32)

2007- up Jeep® Wrangler JK - Neoprene Front Seat Vests.

Protectors designed to be used on JK's equipment with or without seat ABS air bag systems.

Parts included: (1) Front driver's side seat vest  
(1) Front passenger's side seat vest

**Warning: ABS air bag must not be covered by seat protector. Make sure that deployment area is clear of any and all obstructions.**



#### Instructions:

**Step (1)** Slide, and tilt back of seat forward

**Step (2)** Remove Head rest

**Step (3)** Slip protector over back of seat


**Step (4)** Slip lower nylon strap and clip between the upper and lower portions of the seat.

**Step (5)** Slip Velcro straps through lower straps plastic loops as shown.

**Step (6)** position the side straps in front of seat adjuster as shown.  
**Driver's side** adjust seat up as high as possible using the seat height adjuster lever. Slip straps between raised seat and seat riser. Clip straps together and adjust.  
**DO NOT OVER TIGHTEN.**

**Passenger's side** place the rear strap underneath the seat slider and and seat riser. Adjusting the seat forward or backwards may help with locating and pulling inner most tabs near console. The front straps should be run under the front of the seat just behind the seat slider adjustment arm. Adjust straps but **DO NOT OVER TIGHTEN!**

**Step(1)**



**Step (2)**



**Step (3)**



**Step (4)**



**Step (5)**



**Step (6)**





**Installation instructions ( p/n: 13235.30, 13235.32)**

**Step (7)** Slide front and rear lower straps under seat. This step is the same for both the driver's side and passenger's side seat protector. Make sure that the front straps are inserted through the front seat adjuster arm to insure proper operation of seat slider. Clip and adjust. **DO NOT OVER TIGHTEN!**

**Step (7)**



**Step (8)** Adjust all protectors straps for snug fit and pull onto seat in desired position and make sure the vest opening **DOES NOT BLOCK** the seats ABS deployment area. Reinstall head rest and adjust seat back to desired driving position.

