



# INSTALLATION INSTRUCTIONS

## Part Number 33-2024

This filter fits: **See current K&N catalog for complete listing**

**\*FREE K&N DECAL To register your warranty, please see us online at [knfilters.com/register](http://knfilters.com/register). FREE K&N DECAL\***

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter may be used in a stock machine, and no modifications will be required. However there are special installation instructions, so please follow the procedures outlined below to ensure that the K&N Air Filter seals properly.

### Installation

- 1) Remove the stock air filter.
- 2) Remove any hoses and/or wires that will limit the movement of the air box lid.
- 3) Install the K&N Air Filter into the air box base.
- 4) Angle the lid enough to slide the tabs on the air box lid into the corresponding slots on the air box base. Hold enough pressure on the lid to keep the tabs in place while the lid is hinged closed.

**Note: If the rubber seal of the air filter is dry it can be difficult to close the air box lid. Apply a small amount of K&N Oil or sealing grease to allow the air box lid to close easier.**

- 5) Tighten the screws on the lid evenly. Do not overtighten.

**CAUTION! If the lid does not fully close with hand pressure, the air filter is not properly seated into the lid.**

**Do not force the lid closed as this can damage the air box.**

- 6) Reinstall any hoses and/or wires removed in step 2.

**These instructions must be followed every time the filter is serviced, otherwise the filter may not seal, and damage to the engine could result.**

HOLD PRESSURE IN THIS DIRECTION

PRESS DOWNWARD AND TIGHTEN

