




VOLANT AIR INTAKE SYSTEMS
 PART NO.: 17861
 INSTALLATION INSTRUCTIONS
 WWW.VOLANTPERFORMANCE.COM
 TECH SUPPORT: (909) 476-7225


17861 PARTS LIST		3	1/4" WASHERS
1	VOLANT FILTER BOX	1	1/4" LOCK WASHER
1	VOLANT FILTER BOX LID	1	1/4" NUT
1	VOLANT AIR DUCT	4	1/4"-20 TRUSS HEAD SCREWS
1	RAM FILTER W/CLAMP	4	1/4" RUBBER WASHERS
2	#056 CLAMPS	1	1/2" RUBBER GROMMET
1	3 1/4" X 3' SLEEVE	1	VOLANT BRACKET
1	1/4"-20 BOLT	1	1/2" X 15' BREATHER HOSE



SIDE VIEW




LOCATION FOR AIR TEMP SENSOR




- 1/4"-20 BOLT
- 1/4" WASHER
- VOLANT BRACKET
- 1/4" WASHER
- 1/4" LOCK WASHER
- 1/4" NUT

- STOCK BOLT
- 1/4" WASHER
- VOLANT BRACKET

TOP VIEW



RAM FILTER W/CLAMP




VOLANT AIR DUCT

LOCATION FOR AIR TEMP SENSOR

1/2" RUBBER GROMMET

1/2" X 15' BREATHER HOSE



THROTTLE BODY

- #056 CLAMP
- 3 1/4" X 3' HUMP HOSE
- #056 CLAMP