



HOOD SHIELD INSTALLATION and CLEANING

I - Sheet Number STMPDBF38 Rev.A

- 1. Open hood and locate the hood latch behind the grill.
- 2. Carefully disconnect latch from hood by removing (1) screw with a wrench.
- 3. Remove (6) nuts that secure grill to hood. Carefully remove grill from hood and set aside.
- 4. Peel back 2" (5 cm) of tape liner from each end of hood shield.
- 5. Center hood shield on hood. Press firmly to adhere previously exposed tape to underside of hood.
- 6. With the hood shield in its final position, remove remaining tape liner.
- 7. Press firmly along tape flanges to ensure tape had adhered properly to underside of hood.
- 8. Make sure that the front flange of the hood shield is hanging over the grill opening and reattach grill using previously removed (6) nuts.
- 9. OPTIONAL SCREW INSTALL: Screw the self-tapping screw with washer through the predrilled holes in hood shield and into hood. A power screwdriver is recommended, but once the screwdriver penetrates the inside metal panel use a regular phillips screwdriver the remainder of the way.
- 10. Install bump ons at pre-cleaned locations on hood surface.





IMPORTANT: Before driving, ensure the hood shield is properly secured to vehicle. Clean with a **SOFT** cloth and soap and water ONLY! Using abrasive cleaners, chemicals, or solvents will **VOID** the warranty on this product.