



THE AUTOMOTIVE LIGHTING BENCHMARK

# 2005-2013 CORVETTE XB LED HEADLIGHTS INSTALL GUIDE

WARNING: By reading this document, you agree it is only to be used as an educational guide. Morimoto Lighting nor its dealers make guarantees on any finished results, nor are they to be held responsible for any damage, misuse, or personal injuries. If you are unable to clearly understand and adapt the information below, professional installation is recommended.






IMPORTANT: If your vehicle is equipped with anything but OEM turn signals (full assemblies, LED bulbs, or otherwise) in the tail lights or elsewhere: You may experience a hyper flash and/or problem with the sequential signal setting on these headlights. This is not a defect in the headlight, and caused by un-matched impedance with your original vehicle settings.


## PARTS IDENTIFICATION

### STANDARD PARTS

2x HEADLIGHT HOUSINGS




1x DRL HARNESS




# WIRING CONFIGURATION AND INSTALLATION

## WIRING DIAGRAM



DRL WIRING




SEQUENTIAL TURN SIGNAL



MAIN CONNECTION

## DRL HARNESS WIRING

DRL WIRE FROM  
LEFT HEADLIGHT




DRL WIRE FROM  
RIGHT HEADLIGHT


INSERT FUSE TAP  
TO ACC IN FUSEBOX  
(FUSE #6 HAS HAD  
GOOD FEEDBACK)

DRL SPLITTER /  
FUSE TAP

## SEQUENTIAL TURN SIGNAL CONTROL



DISCONNECTED:  
SEQUENTIAL TURN SIGNAL FUNCTION



CONNECTED:  
STANDARD TURN SIGNAL FUNCTION