

Instructions for the **HEAVY DUTY HITCH MOUNT** Flagpole Kit



Flagpole Kit Includes:

- 2"x 72" Polished Aluminum Flagpole - 16 Gauge
- 2" Hitch Mount Flagpole Holder - Fits 2" Hitch Receiver
- 3" Aluminum Silver Ball
- 2" Top Cap installed on Flagpole
- 3' x 5' Nylon Sewn USA Flag (*Note not all vendors add flag)
- 1 - 2" Swivel Sleeve
- Clip Pack: 2 stainless steel clips, top swivel and washer
- 5/8" Trailer Hitch Pin
- Safety Coupler Pin
- Thumb Screw
- Hitch Tightener

STEP 1: Insert your Hitch Mount Flagpole holder into your vehicles hitch receiver and secure it with your 5/8" pin.

STEP 2: Assemble your flagpole. Slide your 2" swivel sleeve over the top of your flagpole then place the top swivel and washer on top of the Top Cap and screw in your aluminum ball.

STEP 3: Add your flag to your flagpole. Clip the top of your flag to the Top Swivel & the bottom of your flag will clip to the first loop on your 2" Swivel Sleeve.

STEP 4: Push in the button located on the flagpole and slide your 2" Swivel Sleeve past the button. This will prevent your flag from rising to the top of the pole.

STEP 5: Insert your flagpole into your flagpole holder.

STEP 6: Insert your Safety Coupler Pin to secure your flagpole.

STEP 7: Tighten your Thumb Screw

STEP 8: Enjoy!

**** NOT RECOMMENDED FOR USE OVER 50 MPH****

FOR PARTS AND SERVICE:

EZPOLE FLAGPOLES/ 1489 EAST 363RD STREET/ EASTLAKE, OHIO 44095

TOLL FREE: 888-454-9164/ LOCAL: 440-951-1011/ FAX: 440-951-2933/ www.ezpole.com



Instructions for the **HEAVY DUTY HITCH MOUNT** Flagpole Kit

Hitch Tightener Installation - Anti-Rattle Stabilizer

Parts Included : As Shown Below

- 2 Flat Washers
- 2 Nuts
- 2 Lock Washers
- 1 Tightener Plate



- Place the U-bolt into place and slide it to touch the face of the hitch.
- Push the tightener plate onto u-bolt from the bottom with the raised end away from the hitch.
- Have the washer, lock washer, and nut to one side of the U-bolt. Hand tighten nut to hold washers in place.
- Tighten the nuts with wrench evenly until metal plate is tight to the stinger and hitch. ****Use 3/4" open wrench or socket****
- Check the nuts periodically to ensure that they remain tight.

