

Universal Front Cargo Seat Cover Installation Instruction

Content: (1) 2 pcs Cargo Seat Cover
(7) Cargo Cover Storage Bags



1. Attach rear cover to front cover by looping the top two strap through buckles as shown. Do Not tighten at this time.



2. If equipped, head rest should be raised or removed.



3. Slip cover over top of seat. Pull down into position. Straps should be placed above and below reclining lever if equipped.



4. Slide front hold down strap between upper and lower seat sections. Reclining the seat will ease strap installation.



5. Adjust side straps to center cover over front and back of seat.



6. If seat is equipped with side air bags make sure straps are clear of deployment zone.




7. Attach top Velcro strap and front hold down strap to back cover.



8. Secure all upper seat straps at this time making sure cover is centered.



9. Pull sides around seat base and attach retainer hooks to suitable points under seat base.



10. Test all seat functions. Hooks and straps should not effect seat movement.



11. Inspect and make any final adjustments needed.



12. Attach Cargo bags as desired.

