

KIT105

Chevrolet (BJ143, BJ144)

Installation

1. Press lower ball joint, install castle nut and torque to 35 ft. lbs. Do not install cotter key at this time.
2. Press in the upper ball joint, install castle nut and torque to 70 ft. lbs. Advance castle nut to next slot and install cotter key.
3. Retorque the lower ball joint castle nut to 150-160 ft. lbs. Advance castle nut to next slot and install cotter key.

PLEASE NOTE:

Apex ball joints are designed and manufactured with very close tolerances and precise factory preloads.

This may cause an initial period of tight steering and /or memory steer after install.

As with many performance upgrade parts, these may require a performance break in period of 200-500 miles before they settle into your vehicle.

Thanks for choosing Apex Performance upgrade!

KIT105

Chevrolet (BJ143, BJ144)

Installation

1. Press lower ball joint, install castle nut and torque to 35 ft. lbs. Do not install cotter key at this time.
2. Press in the upper ball joint, install castle nut and torque to 70 ft. lbs. Advance castle nut to next slot and install cotter key.
3. Retorque the lower ball joint castle nut to 150-160 ft. lbs. Advance castle nut to next slot and install cotter key.

PLEASE NOTE:

Apex ball joints are designed and manufactured with very close tolerances and precise factory preloads.

This may cause an initial period of tight steering and /or memory steer after install.

As with many performance upgrade parts, these may require a performance break in period of 200-500 miles before they settle into your vehicle.

Thanks for choosing Apex Performance upgrade!