



INTAKE SYSTEMS FOR VEHICLES LISTED ARE 50 STATE LEGAL. SEE KNFILTERS.COM FOR CARB STATUS ON EACH PART FOR A SPECIFIC VEHICLE.


INSTALLATION INSTRUCTIONS

57-3021-1 CHEVROLET / GMC 1999-2004 Silverado / Sierra V8-4.8L / 5.3L (Except 2500 models)

NOTE: This kit was not designed to fit vehicles with a body lift.

TOOLS NEEDED:

- Flat Blade Screwdriver
- 4mm Allen Wrench
- 10mm Wrench
- Ratchet
- 10mm Socket
- 13mm Socket



PARTS LIST:

Description	Qty.	Part #	Description	Qty.	Part #	Description	Qty.	Part #
A Intake tube	1	08740	H Hex bolt	1	07844	O 3.75"ID x 2"L silicone hose	1	08631
B Heat shield	1	07415	I Rubber Mntd stud	3	07027	P Gasket	2	09033
C Air Filter	1	RF-1041	J Wave Washer	1	08239	Q Trim seal 48"	1	102485
D Adapter	1	08783	K 1/4"ID x 5/8"OD flat washer	5	08275	R Hose clamp #60	2	08624
E "L" bracket	1	070812	L 5/16"ID x 5/8"OD flat washer	1	08276	S Hose clamp #64 midi	2	08650
F "C" bracket	1	070822	M Nylock nut	5	07553	T Hose clamp #104	1	08697
G Allen bolt	3	08320	N 4"ID x 1.5"L silicone hose	1	08755			

NOTE: FAILURE TO FOLLOW INSTALLATION INSTRUCTIONS AND NOT USING THE PROVIDED HARDWARE MAY DAMAGE THE INTAKE TUBE, THROTTLE BODY AND ENGINE.

TO START:

1. Turn off the ignition and disconnect the negative battery cable.
NOTE: Disconnecting the negative battery cable erases pre-programmed electronic memories. Write down all memory settings before disconnecting the negative battery cable. Some radios will require an anti-theft code to be entered after the battery is reconnected. The anti-theft code is typically supplied with your owner's manual. In the event your vehicles' anti-theft code cannot be recovered, contact an authorized dealership to obtain your vehicles anti-theft code.



2. Disconnect the mass air sensor electrical connection.



3. Loosen the hose clamp on the intake hose at the mass air sensor.




4. Loosen the hose clamp on the intake tube at the throttle body.




5. Using a flat blade screwdriver, pry the radiator hose retaining clip from the intake tube.



6. Detach the intake hose from the mass air sensor.




7. Detach the intake tube from the throttle body and remove the intake assembly.



8. Pull firmly upward and remove the airbox.
NOTE: K&N Engineering, Inc., recommends that customers do not discard factory air intake.




9. Loosen the hose clamp and remove the mass air sensor from the airbox.



10. Assemble the mass air sensor, heat shield and adapter using the gasket and hardware provided.



11. Install the trim seal onto the heat shield as shown.
NOTE: Some cutting and trimming may be necessary to achieve best fit



12. Attach the rubber mounted stud to the "C" bracket.
NOTE: Do not tighten completely at this time.




13. Attach the "C" bracket assembly to the heat shield as shown.
NOTE: Do not tighten completely at this time.




14. Attach the rubber mounted stud to the "L" bracket.
NOTE: Do not tighten completely at this time.



15. Attach the "L" bracket assembly to the heat shield.
NOTE: Do not tighten completely at this time.



16. Loosen and remove the two bolts on the airbox mounting tray.
NOTE: One of these bolts will not be reused.



17. Install the rubber mounted stud into the threaded hole in the airbox mounting tray as shown.



18. Install the heat shield assembly.



19. Secure the "C" bracket to the threaded hole in the airbox mounting tray using the bolt removed in step 16.



20. Secure the "L" bracket to the threaded hole in the radiator core support using the hardware provided.



21. Secure the heat shield to the rubber mounted stud using the hardware provided.



22. Install the 4"ID silicone hose onto the intake tube.
NOTE: Do not tighten the hose clamps at this time.




23. Install the 3.75"ID silicone hose (08631) onto the intake tube.

NOTE: Do not tighten the hose clamps at this time.



24. Install the intake tube and tighten the hose clamp on the silicone hose at the throttle body.



25. Align the intake tube with the mass air sensor and tighten the hose clamp on the silicone hose at the mass air sensor.



26. Align and check the intake tube for clearance, tighten the hose clamp on the silicone hose at the intake tube.



27. Tighten the hose clamp on the silicone hose at the intake tube.

28. Go back and tighten the hardware that mounts the brackets and heat shield.



29. Due to production tolerances it may be necessary to mark the fan shroud as indicated, remove the intake tube and trim the fan shroud.
NOTE: Be sure to cover the throttle body and alternator during this process.



30. Install the Air filter element and secure with hose clamp.



31. Reconnect the mass air sensor electrical connector.

32. Reconnect the vehicle's negative battery cable. Double check to make sure everything is tight and properly positioned before starting the vehicle.

33. The C.A.R.B. exemption sticker, (attached), must be visible under the hood so that an emissions inspector can see it when the vehicle is required to be tested for emissions. California requires testing every two years, other states may vary.

34. **NOTE:** Most General Motors vehicles have the Vehicle Emissions Certification Information (VECI) label affixed to the air filter box. In order to be compliant with California emissions laws, the label **MUST** remain in the engine compartment. If the Vehicle Emission Control Information label is removed during modification, a new replacement label must be obtained and installed in a readily visible position in the engine compartment. The label shall not be affixed to any equipment which is easily detached from the vehicle. We recommend that the label is affixed to the underside of the hood adjacent to the hood latch. The label is Vehicle Identification Number dependent and can be ordered from the vehicle dealership. In order to receive the proper decal please bring your VIN with you. Failure to have the VECI under the hood may result in failure of a pre-registration smog test.

35. It will be necessary for all K&N® high flow intake systems to be checked periodically for realignment, clearance and tightening of all connections. Failure to follow the above instructions or proper maintenance may void warranty.

ROAD TESTING:

1. Start the engine with the transmission in neutral or park, and the parking brake engaged. Listen for air leaks or odd noises. For air leaks secure hoses and connections. For odd noises, find cause and repair before proceeding. This kit will function identically to the factory system except for being louder and much more responsive.

2. Test drive the vehicle. Listen for odd noises or rattles and fix as necessary.

3. If road test is fine, you can now enjoy the added power and performance from your kit.

4. K&N Engineering, Inc., requires cleaning the intake system's air filter element every 100,000 miles. When used in dusty or off-road environments, our filters will require cleaning more often. We recommend that you visually inspect your filter once every 25,000 miles to determine if the screen is still visible. When the screen is no longer visible some place on the filter element, it is time to clean it. To clean and re-oil, purchase our filter Recharger® service kit, part number 99-5050 or 99-5000 and follow the easy instructions.

INTAKE SYSTEMS FOR VEHICLES LISTED ARE 50 STATE LEGAL. SEE KNFILTERS.COM FOR CARB STATUS ON EACH PART FOR A SPECIFIC VEHICLE.