



**STREET SCENE EQUIPMENT, INC.**

365 McCormick Avenue  
 Costa Mesa, CA. 92626  
 Phone (714) 426-0590 Fax (714) 426-0591

950-16120  
 1988 - 1998 GM CK TRUCKS  
 &  
 1992-1999 SUBURBAN/TAHOE  
 ELECTRIC CAL-Vu MIRROR  
 WITH HEATED GLASS  
 CONVERSION KIT

**INSTALLATION INSTRUCTIONS**

**NOTE:** Please check year, make, and model against application part number. Be sure both mirror heads and mounting plates are left & right side before painting. Parts that have been painted are not eligible for return.

**NOTE:** If Painting Mirrors Tape Over Threads To Keep Paint Off

**NOTE:** Check Your Mirror Plugs To Make Sure They Plug Into Your wire harness before painting, If painted warranty will be void.

**NOTE:** Mirrors are designed for specific year vehicles. Although mirror may appear to be the same, the electrical connectors will vary year to year. If your mirror does not plug into your factory wire harness, please check your part number and application guide.

**NOTE:** Do Not Use Loctite On Threads. Warranty Will Be Void If Used

**NOTE:** Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

**NOTE:** Do Not Over Tighten Nuts, Mounting Brackets Will Crack

**VERY IMPORTANT !** Read and understand all directions, then check the following parts list before starting installation.

PARTS LIST					
2	Mirror Heads	1	Instruction Sheet	6	Six mm Nuts
2	Mirror Plates	1	Street Scene Decal	2	Foam Rubber Strips

TOOL LIST
Phillips screwdriver, 8mm combination wrench, 10mm combination wrench, door panel clip & trim pad removal tool GM part number : J 38778 or equivalent window crank removal tool GM part J 9886-01 or equivalent, manual windows only.

**SECTION 1 88 - 94 GM CK TRUCK**

1. Roll down windows and remove armrest screw using phillips screwdriver.
2. If equipped with manual windows, remove window crank with handle removal tool.
3. If equipped with power windows, remove Power Assist Control Panel using the panel removal tool. Lift from the front to detach clips.
4. Remove retaining clips from back of the three switches located on the Control Panel.

- 5 . Remove screw from behind panel and unplug wiring from Control Panel by releasing retaining clips.
- 6 . Using the GM Removal Tool, slide under edge of door panel and lift to pop off clip, move around panel with tool releasing all of the clips. Lift panel upward to remove.
- 7 . Remove nylon clips from inner door and reinstall onto door panel.
- 8 . Remove foam mirror access plug from door.
- 9 . Unplug wire harness connector, then remove stock mirror with 10 mm wrench.
- 10 . Install Cal-Vu mounting plates to mirror heads ( nuts provided ) using an 8 mm wrench. Install adhesive backed foam rubber strips to mounting plate. Align each strip with the mark located 3/4 inch from the bottom of the mirror plate, remove backing, then apply strip.
- 11 . Remove gasket from stock mirror plate and install on the Cal-Vu mirror. ( some trimming may be necessary for best fit. )
- 12 . Install Cal-Vu mirror using stock hardware, then plug in wire harness connector.
- 13 . Install foam mirror access plug into door.
- 14 . Install door panel by placing window seal portion of panel over door frame the lining clips up with holes. Use the palm of your hand to pop in place.
- 15 . On power windows equipped trucks, plug wiring into control panel, replace screw and pop panel into place. Install armrest screw.

## **SECTION II 95 - 97 GM CK TRUCK**

- 1 . Roll down windows and remove the mirror trim piece at the upper end of door panel. This is easily removed by using the panel removal tool to pop open the plastic retaining clip. Remove clip from inner door and replace onto trim piece.
- 2 . Remove foam mirror access plug from door.
- 3 . Unplug wire harness connector, then remove the three mounting 10 mm nuts which fasten the mirror to the door to remove mirrors.
- 4 . Install Cal-Vu mounting plates to mirror heads ( nuts provided ) using an 8 mm wrench.
- 5 . Install adhesive backed rubber strips to mounting plates. Align each strip with the mark located 3/4 inch from the bottom of the mirror plate, remove backing , then apply strip.
- 6 . Remove stock gaskets and install on your Cal-Vu mirrors.
- 7 . Install mirrors, tightening nuts fully, then plug in wire harness connector.
- 8 . Replace foam mirror access plug.
- 9 . Install trim piece by sliding the bottom in first and then snapping firmly at the top.



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

### CONNECTING STREET SCENE HEATED MIRROR CONVERSION KIT

1988-1998 CHEV/GMC/CK TRUCKS

1992-1999 SUB/TAHOE/YUKON

CREW CABS

### Connecting Street Scene Heated Mirror Conversion Kit

#### Instructions For Part Numbers:

<b>950-16120</b>	<b>950-20120</b>	
<b>950-17120</b>	<b>950-26120</b>	
<b>950-19120</b>	<b>950-27120</b>	

#### SPECIAL NOTE:

If you are installing Street Scene Mirrors with Signal option, the wiring for the heaters will have a push on terminal and a ring connector on. The wires for the signal system will have no connectors on them. **Do not mix up**

1. Install Street Scene Heated Mirrors following mirror installation instructions.
2. Mount the switch in a suitable location. A good place is on the lower dash panel. Drill a 1/2" diameter hole and insert the switch from the front side and install the nut from the backside and tighten.

#### NOTE: LOCATION OF WIRES ON SWITCH

**Top Of Switch: ( Marked "Earth" ) Black wire from four foot power connecting harness.**

**Center Of Switch: ( Marked "Load" ) Red wires from right & left mirror heaters.**

**Bottom Of Switch: ( Marked "Supply" ) Red wire from four foot power connecting harness.**

Locate a switched 12 volt power supply at the fuse panel ( Power goes off when ignition switch is in the " off " position). Using the blue quick splice connector supplied, crimp the Red wire from the switch harness to the wire found at the fuse block. DO NOT connect to a constant 12 volt power supply.

3. Remove the right and left kick panels.
4. Run the **Red / Black** wire on the mirror into the door. Pull out the rubber boot from the door and door frame. Guide the wire harness through the door and out the hole vacated by the boot. Remove any slack.
5. Pass the wire harness through the rubber boot between the door and the door frame.
6. Guide the wire harness through the door frame and into the vehicle.
7. Do the same on the passenger side. Run the wire across the dash to the left side of the steering column.
8. Connect the **RED** wire from the right and left wire harness to the center pin on the switch using the " **One to Two** " connector.
9. Attach the **BLACK** wires with the ring connectors to a suitable nearby ground location on the metal framework on the vehicle.