



# STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue  
Costa Mesa, CA. 92626  
Phone (714) 426-0590 Fax (714) 426-0591

950-16724  
2004  
FORD F-150  
ELECTRIC MIRRORS  
WITH HEATED GLASS  
CONVERSION KIT

## INSTALLATION INSTRUCTIONS

**NOTE:** Please check year, make, and model against application part number. Be sure both mirror heads and mounting plates are left & right side before painting. Parts that have been painted are not eligible for return.

**NOTE:** Check Your Mirror Plugs To Make Sure They Plug Into Your wire harness before painting, If painted warranty will be void.

**NOTE:** Mirrors are designed for specific year vehicles. Although mirror may appear to be the same, the electrical connectors will vary year to year. If your mirror does not plug into your factory wire harness, please check your part number and application guide.

**NOTE:** Do Not Use Loctite On Threads. Warranty Will Be Void If Used

**NOTE:** Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

**NOTE:** Do Not Over Tighten Nuts, Mounting Brackets Will Crack

**NOTE:** If Painting Mirrors Tape Over Threads To Keep Paint Off

**VERY IMPORTANT !** Read and understand all directions, then check the following parts list before starting installation.

PARTS LIST					
2	Mirror Heads	1	Instruction Sheet	6	6 mm Nuts
2	Mirror Plates	1	Street Scene Decal		

1. Open door and lower windows.
2. Remove door panel by:
  - A - Pry out the plastic trim behind door release handle and remove the bolt located behind it.
  - B - Lift out window control panel. Disconnect wiring from window control panel. Remove the bolt located behind it.
  - C - Remove the speaker grille. Pry gently taking care not to break tabs. Remove the four screws securing speaker. Remove speaker from door and disconnect wire.
  - D - Pry out the two upper white speaker attaching stand offs. These must be re-used so take care when removing.
  - E - Remove the two screws on the bottom side of door panel. Lift door panel up and away from door to remove.
3. Peel off foam installation from corner of door and disconnect mirror wire.
4. Remove mirror mounting nuts. Save for re-use.
5. Grasp mirror and remove with a up / down side to side rocking motion.
6. Remove foam gasket from backside of mirror.
7. Attach mounting plate to mirror with nuts provided, Tighten securely. **DO NOT** over tighten or use loctite on threads. On electric mirrors guide wire plug through center hole in plate. Install gasket removed in step 6 to plate.
8. Install mirror to door, while guiding wires through hole in door and into cab. Secure mirror to door using three nuts from the OEM mirror.
9. Connect wire harness to mirror plug.
10. Install door panel by lining up hooks on door panel with slots in door and sliding panel down.
11. Install all remaining items in reverse order of removal.



## STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue  
Costa Mesa, Ca. 92626  
Phone (714) 426-0590 Fax (714) 426-0591

**CONNECTING  
STREET SCENE  
HEATED MIRROR  
CONVERSION KIT  
2004  
FORD F-150**

### Connecting Street Scene Heated Mirror Conversion Kit

Instructions For Part Numbers:		
950-16724	950-19724	950-26724
950-17724	950-20724	950-27724

#### SPECIAL NOTE:

If you are installing Street Scene Mirrors with Signal option, the wiring for the heaters will have a push on terminal and a ring connector on. The wires for the signal system will have no connectors on them. **Do not mix up**

1. Install Street Scene Heated Mirrors following mirror installation instructions.
2. Mount the switch in a suitable location. A good place is on the lower dash panel. Drill a 1/2" diameter hole and insert the switch from the front side and install the nut from the back side and tighten.

#### NOTE: LOCATION OF WIRES ON SWITCH

**Top Of Switch: ( Marked "Earth" ) Black wire from four foot power connecting harness.**

**Center Of Switch: ( Marked "Load" ) Red wires from right & left mirror heaters.**

**Bottom Of Switch: ( Marked "Supply" ) Red wire from four foot power connecting harness.**

Locate a switched 12 volt power supply at the fuse panel ( Power goes off when ignition switch is in the " off " position ). Using the blue quick splice connector supplied, crimp the Red wire from the switch harness to the wire found at the fuse block. DO NOT connect to a constant 12 volt power supply.

3. Remove the door sill plates and the right and left kick panels.
4. Run the **RED / BLACK** wire from the mirror into the door. Pull out the rubber boot between the door and door frame. Guide the wire harness through the door and out the hole vacated by the boot. Remove any slack.
5. Pass the wire harness through the rubber boot between the door and door frame.
6. Guide the wire harness through the door frame and into the vehicle.
7. Do the same on the passenger side, Run the wire across the dash to the left side of the steering column.
8. Connect the **RED** wires from the right and left wire harness to the center pin on the switch using the " **One to Two** " connector.
9. Attach the **BLACK** wires with the ring connectors to a suitable nearby ground location on the metal framework on the vehicle.