





GATHER THESE TOOLS FOR ASSEMBLY & INSTALLATION
 7/16" wrench, T45 Torx socket, 7/16" socket, 3/8" drive ratchet - 3/8" socket
 One 1/8" square end driver bit provided - Electric drill/driver/18V cordless
 One each; carpenters square, mallet, tension clamps
 One each; Phillips and blade screwdrivers, 1/2" wrench



Transit Connect Full/Half Installation Instructions

1 Check contents against parts list. Examine contents for damage caused by shipping. Make sure that you have the required tools for assembly, as listed above. NOTE: Drawer Tray is assembled upside-down for ease.

2 Lay out the Drawer Side Rails with Pinch Point Sticker facing down, bearing track should be outward. NOTE: Drawer Tray is assembled upside-down and Support Rails will follow. Position the Rear Drawer Face opposite the end with the Pinch Point Stickers and use tension clamps to secure in place. (See Pic.1) Align pre-drilled holes and attach using the screws provided in Hardware Bag #1. (See Pic.1a & 1b).





3 Starting with the Tray Cross Channel containing the Latch, loosen the nuts on the attached rail plates and insert into channel on Drawer Side Rail (See Pic.2a) and slide toward Rear Drawer Face stopping just beyond factory marks and tighten. (See Pic.2b) Latch should be located on right side of drawer. Repeat with the remaining two (2) Tray Cross Channels. (See Pic.2c)



NOTE: The Latch on the Tray Cross Channel should be on your right side.

(3) Full Length - (2) Half Length





(3) Full Length - (2) Half Length

4 Attach the Drawer Pull / Face by aligning with pre-drilled holes using clamps and making sure that each Drawer Side Rail is located under the lip of the Drawer Pull / Face. (See Pic.3a) Using a electric drill/driver/18V cordless, drill screws into Drawer Pull/Face to secure. (See Pic.3b) Using ratchet and 7/16" socket, tighten the nuts on the Tray Cross Channels. (See Pic.3c) Be sure to check your alignment with the factory marks.


Jotto-Cargo Slide Installation Instructions

5 Remove the E-Clip (See Pic.4) from Latch Control Cable. Insert the Latch Control Cable through pre-drilled holes in center of first two(2) Tray Cross Channels. Run the Latch Control Cable through the appropriate hole on the Tray Cross Channel w/ Latch Assembly. (See Pic.5)


6 First, insert dog leg end of latch cable into latch pin assembly; may help to push in on pin assembly. (See Pic .6) Then, push cable into tab in cross channel and snap E-clip onto notch in cable. (See Pic.7)



7 Insert screws and through Latch Control Cable bracket and pre-drilled holes on Drawer Pull / Face and secure with supplied Nylock Nuts using a phillips screw driver and wrench. NOTE: Nuts should attach to the bracket side. (See Pic.8 & Pic.9)





8 Once tray is assembled, slide each of the Frame Side Rails(2) into the track, channel side up. (See Pic.10) (NOTE: The latch must be disengaged to allow Frame Support Rail to slide fully into place.) With Frame Side Rails in place, slide the front Frame Support Rail with pre-attached rail plates into channel and push toward front, stopping at mark. Insert middle bracket with hole facing away from center of the tray then insert center support. (See Pic.11)



Jotto-Cargo Slide Installation Instructions

9 Now slide one(1) support bracket into each channel toward the front and stop, then slide final Frame Support Rail in place for brackets. NOTE: All three(3) Tray Cross Channels come w/ pre-drilled holes. (See Pic.12-14) Align Frame Support Rail with factory mark, and tighten the 1/4-20 flange nuts. Using an electric drill/driver/18V cordless, drive the supplied screws in Bag#1 securing slide support bracket Frame Support Rail, then tighten down the 1/4-20 flange nuts. (See Pic.15-18) Insert and carefully tighten the (2) Radial Bearings in the area located under the Front Tray Cross Channel and the Drawer Pull/Face. (See Pic.19) Tap in the provided End Caps(6) into the Tray Cross Channels. (See Pic.20)



PRE-ASSEMBLY COMPLETE. PROCEED TO TRUCK BED INSTALLATION.





Jotto-Cargo Slide Installation Instructions

NOW FOR THE COMPLETE INSTALLATION.

10 Clean any obstructions from rear of vehicle before attempting final installation. (See Pic.21) With a friend, place assembled Jotto-Cargo Slide into Transit Connect cargo area and check clearance of Drawer Pull/Face. (See Pic.22)



11 Remove tie downs from rear of vehicle (See Pic.23a). From mid-area of cargo area by each sides wheel well remove a bolt from the D/S and rubber grommet from the P/S to allow securing of Cargo Slide brackets into Transit Connect. (See Pic.23b) Slide front bracket into place to mark hole locations for AVK fastener - **only on full.** (See AVK install Sheet) When finished with AVK, align Cargo Slide brackets with hole openings. The (2) front brackets will require provided 1 1/2" hex head bolts - **only on full.** (See Pic.24) The (2) Middle bolts will require (1) OEM D/S bolt and (1) provided button head M10 bolt. (See Pics. 25) Secure rear bracket using OEM bolts from Transit Connect tie downs. (See Pics. 26)



Jotto-Cargo Slide Parts Assembly

FRAME ASSEMBLY



FRAME SIDE RAILS (2)



FRAME SUPPORT RAILS
(3) Full Length / (2) Half Length



SUPPORT BRACKETS (2)

DRAWER ASSEMBLY



DRAWER SIDE RAILS (2)




FRONT AND REAR FLOOR CLEATS (2)



DRAWER PULL / FACE (Rear Doors End)



REAR DRAWER FACE (Seat End)



TRAY CROSS CHANNELS
(3) Full Length / (2) Half Length


FINAL ASSEMBLY



LATCH CONTROL CABLE




PULL HANDLE



DOG LEG



RADIAL BEARINGS (2)



END CAPS (6)



INSTALLATION DVD



(2) Full Length
Attachment brackets



(2) Half Length
Attachment brackets

DRAWER BOTTOM - A piece of plywood 5/8" - 3/4" thick is commonly used. Cut to the size of your tray. Plywood must be cut square, either cut yourself or at your local lumber outlet.

Full Size 46" X 63": CUT 39.25" X 60.25"



Full Size 46" X 44": CUT 39.25" X 41.75"

*NOTE: If your Jotto-Cargo Slide is overly exposed to the elements, we recommend a marine grade plywood or our optional Aluma Plank System.

**ALUMA PLANK FLOORING SOLD SEPARATELY
PLEASE SEE INSTALLATION DVD FOR
INSTRUCTIONS ON APPLICATION.**

Questions? Contact your local dealer or try our LIVE Online Customer Support!
For additional questions call 877-455-6886 - www.jottocargoslide.com

----- WARNING -----
SEE WEIGHT DISTRIBUTION DIAGRAM
BEFORE LOADING AND USING TRAY



**Please Observe & Do Not Exceed
Vehicle Weight Capacity, and Use
Even Distribution with Slide!**