

# 55309 KIA SEDONA

## English

### WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



#### MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

#### ¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

#### À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filéée.

6/23/2014

1. Open the rear hatch of the vehicle. Remove the rear threshold plate by carefully pulling off the screw caps and removing the screws holding it in place (A,B).

2. Partially remove the side rear trim panels by first removing the screw on the threshold and the two cargo net brackets on each side of the vehicle (C,D,E).

3. On the driver's side, the taillight wiring harness will be located inside the square hole near the vehicle threshold. Use care as the edges in/near the hole may be sharp. If a gray piece of foam is present, remove it to access the wire harness (F). Carefully pull the black coated wire loom from the hole to expose the white connectors (G). Separate the connectors and insert the T-Connector end with the yellow wire between the separated connectors and lock into place. Route the 4-flat behind trim panel and out the jack storage compartment.

4. Route the T-Connector end with the green wire behind the passenger side trim panel. The wire harness will be located half way up, just left of the seat belt retractor. Separate the connectors and insert the T-Connector end with the green wire between the separated connectors and lock into place.

#### WARNING!

Verify miscellaneous items the may be hidden behind or under any surface before drilling to avoid damage and or personal injury.

5. Locate a suitable grounding point. Drill a 3/32" hole and secure the white wire using the eyelet and screw provided. Do not drill into any exposed surfaces.

6. Replace all trim panels removed during installation.

7. Route the four flat to the center of the vehicle and out the hatch for use. Store the 4-flat in the jack storage compartment in a convenient out of the way location when not in use.

**INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813**

