

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST! All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

IDEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filetée.

5/13/2010

English 1. Open the rear hatch and remove the behicles rear cargo area cover. A Remove the rear storage tray by lifting up and pulling out. B Remove rear scuff panel by removing plastic fasteners holding it in place. C Remove drivers side storage tray by removing two plastic nuts holding it in place. D

2. Under the storage compartment locate the vehicles trailer tow connector. Elt will mate with the connector on the harness. Insert connector into vehicles connector, make sure the connectors are fully inserted with locking tabs in place. F

3. Adhere the black converter box to the frame of the car using the double-sided tape provided. F Secure any loose parts of the T-connector with the cable ties provided.

4. Re-install the drivers side cargo tray routing the 4-flat between the cargo tray and the drivers side rear trim panel. Route the 4-flat wire to the center of the vehicle and out the trunk when in use. When not in use roll up and store in the rear cargo tray. Re-install anything removed during install.

5. Some vehicles may require the installation of a 20 amp mini fuse in the TOWING position of the fuse panel to function properly. Locate the fuse panel under the hood at the driver side and install a 20 amp mini fuse if necessary.





