



**2007-2008 CHEVROLET TAHOE / GMC YUKON**  
4.8L & 5.3L ENGINE

03/08/12

**Removal:**

- 1) Raise the vehicle up on a hoist or rack to working height. If you do not have access to a hoist or rack raise the vehicle and support securely with jack stands.
- 2) Support the muffler with a stand. Using a hacksaw or sawsall, cut the stock tailpipe in front of the rear end behind the muffler hangers. Separate the wire hanger on the tailpipe from the rubber mount on the vehicle and remove the tailpipe from the vehicle.
- 3) Using a 15mm wrench, remove the two nuts at the flanged connection behind the converter and separate the three wire hangers from the rubber mounts on the vehicle frame and lower the inlet pipe and muffler from the vehicle.

**Installation:**

- 1) Before installing anything, prep the clamps supplied in the hardware kit by removing the nuts, and applying a thick lubricant such as white grease or anti-seize to the threads.
- 2) Place inlet pipe **#26249** into position behind the flange that is welded to the back of the catalytic converters. Connect the wire hanger to its rubber mount and re-install the factory nuts on the flange connection.
- 3) Connect the inlet of muffler **#530562** to the inlet pipe and install the provided 3" clamp. Tighten just enough to hold in position.
- 4) Look at the top rear shock mount through the wheel well opening on the driver's side of the vehicle. You will see a 1/2" x 3/4" hole through the shock mount. This hole is where hanger **#312HA** will be mounted. Place the provided 3/8" flat washer onto the 3/8" bolt and from the bottom of the shock mount, push the bolt through the hole from the inside out. Place hanger **#312HA** with the hanger rod facing outward onto the bolt and secure with the provided washer, lock washer and nut. Make sure the hanger is straight up and down, and then tighten securely. Place rubber hanger **#HA168** onto the bottom of frame hanger **#312HA**.

- 5) Look at the rear end housing at the top; you should see a bracket bolted to it holding the brake lines. Unbolt the brake line from the bracket then unbolt the bracket from the rear end housing. In a vise, straddle the bracket between the jaws and tap the bolt out of the bracket carefully not to damage the threads. It is press fitted and requires some force to remove it; a rubber mallet works best. Take bracket **#HA594** and bolt the longer end to the rear end housing using the original bolt. Take the 5/16" bolt, washer, lock washer and nut and fasten brake lines to the new bracket. This should move your brake lines forward about 1" to assure clearance from the tailpipe.
- 6) Place right side tailpipe **#16758** into position over the axle and slip into the right side muffler outlet. Connect the hanger at the rear of the pipe to the rubber mount on the vehicle. Install the provided 2 1/2" clamp hanger assembly **#339HA** onto the tailpipe and into the factory rubber mount and tighten just enough to hold in position.
- 7) Place the front section of the left side tailpipe **#16508** into the left side muffler outlet and connect the hanger on the pipe to the rubber mount on the vehicle. Tighten the 2 1/2" clamps on the muffler outlets just enough to hold in position.
- 8) Connect the rear section of the left side tailpipe **#16510** onto the back of the front section by sliding the two sections together at the slip-fit connection over the rear axle. Place the hanger at the rear of the tailpipe into the rubber mount installed in step 4. Install a provided 2 1/2" clamp onto the over-axle slip-fit connection. Tighten just enough to hold in position.
- 9) Slide the exit pipe **#16317** for the right/left side and slide the stainless tips **#ST396** onto the ends of the exit pipes. Rotate the pipes and tips to the desired distance from the fender. Place a 2 1/2" clamp onto these slip-fit connections and tighten just enough to hold in position. Also, tighten the clamps on the tips.
- 10) Adjust the position of all muffler, pipes and tips to provide a satisfactory fit. Maintain a minimum of 3/4" clearance between the Flowmaster system, the drivetrain and chassis components, while also keeping suspension travel and vibration in mind.
- 11) Tighten down all clamped connections securely. After the system is secure, slide the 1/2" hanger keepers onto the end of the inlet pipe and the right tailpipe clamp hanger. Slide the 7/16" hanger keepers onto the ends of the hangers at the rear of the vehicle. This will prevent the hangers from slipping out of the rubber mounts.
- 12) For a cleaner appearance and more secure installation, we highly recommend welding all slip-fit connections. If you live in a geographical area that has harsh winters or sees a great deal of precipitation, the use of high temperature paint over the welded areas can help to prevent surface rust and premature corrosion.

## PACKING LIST

<u>Qty</u>	<u>Description</u>	<u>Part#</u>
1	Inlet Pipe	26249
1	Muffler	530562
1	Right Tailpipe	16758
1	Left Tailpipe, Front	16508
1	Left Tailpipe, Rear	16510
2	Side exit pipe (R/L)	16317
2	Stainless tips	ST396
1	Parts Kit	PK458
1	Frame Hanger, Rear	312HA
1	Bracket Hanger	HA594
1	Rubber Hanger	HA168
1	3" Clamp	MC300G
5	2 1/2' Clamp	MC250S
1	5/16" x 3/4" Bolt	HW203
1	5/16" Flat Washer	HW302
1	5/16" Lock Washer	HW308
1	5/16" Nut	HW102
1	3/8" x 1" Bolt	HW208
1	3/8" Flat Washer	HW303
1	3/8" Lock Washer	HW309
1	3/8" Nut	HW103
2	1/2" Hanger Keeper	HW503
4	7/16" Hanger Keeper	HW502



Installation diagram for:  
**SYSTEM #17430**  
2007-2008 CHEVROLET TAHOE / GMC YUKON  
4.8L & 5.3L ENGINE

