

**6392121/
6392121-BK**
2015 GMC Sierra HD



**6392121/
6392121-BK**
2015 GMC Sierra HD

2015 GMC Sierra HD

TORCH Series LED Light Kit 2 - 3" LED Cubes Bracket Kit

TORCH Series LED Light Kit Bracket Kit

TOOLS REQUIRED:

10mm Socket
13mm Socket
14mm Socket
Ratchet and Extensions

PARTS LIST 6392121

(2) 3" LED Light Cube
(2) LED Light Cradles
(1) Driver Light Mount Bracket
(1) Passenger Light Mount Bracket
(4) M6 Nylock Nuts
(4) M6 Socket Head Screw
(2) M8 Lock Nuts
(2) M8 Lock Washers
(2) M8 Bolts
(1) Torx L Key

PARTS LIST 6392121-BK

(1) Driver Light Mount Bracket
(1) Passenger Light Mount Bracket



PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquiries can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1

Begin by opening the hood and marking the relation between the hinge and hood. Use a piece of tape so you can ensure proper hood alignment when installation is complete. (Fig 1)



Step 2

Loosen the two bolts securing the hood hinge.(Fig 2)



**6392121/
6392121-BK**
2015 GMC Sierra HD



**6392121/
6392121-BK**
2015 GMC Sierra HD

Step 3

Secure the LED Light into the bracket. Loosely secure the assembly to the bracket. Two holes are provided for adjustment between lights. (Fig 3)



Step 4

Secure bracket to hood hinge with factory bolts. Repeat on opposite side of vehicle. (Fig 4)



Step 5

Wire LED Light via our T-Rex optional wiring harness kit (part# 639HAR1) or custom wiring harness. T-Rex recommends Torch Lights be wired with our optional wiring harness kit (part#639HAR1). To adjust the angle of your Light Bar, rotate the Light Bar to adjust the angle, then tighten the hardware once the desired angle is achieved (please be careful not to over tighten the mounting hardware). It is best to adjust the angle with the vehicle on level ground with lights facing a wall, garage door or other solid barrier. We recommend checking from a distance of 25'. Your installation is now completed. (Fig 5)

