

**RANCH HAND**

**1-800-366-9712**

**INSTALLATION INSTRUCTIONS**

**2015-up CHEVY TAHOE / SUBURBAN GRILL GUARD:**

**PART # GGC15HBL1**

\*\*\*\* Included in your bolt pack are tabs to cover the two center sensors on 2014 and 2015 GM vehicles equipped with front park assist sensors. Due to the inconsistency of the sensor function, once an aftermarket Grill Guard is installed we have found this to be an effective means of eliminating errors in the system. This in no way is intended to disrupt the function of the Park Assist system, only to prevent the system from recognizing the grill guard as an obstacle and allow you to gain the protection of the grill guard. \*\*\*\*

*NOTE: Will NOT work with vehicles with sensors. Unless using USCBP.*

*NOTE: Will NOT fit if vehicle is equipped with Selective Cruise Control.*

*NOTE: On vehicles without tow hooks, you will need to cut the bumper in order to install the mounting brackets.*

1. To the right and left side of the license plate, you will see two vertical lines. Cut along those lines to remove the plastic for the mounting brackets.
2. On the bottom of the frame you will see a 5/16" round hole. Drill that hole out to 1/2".
3. There is a driver and passenger side mounting bracket. Slide the bracket through the opening of the bumper and then against the frame.
4. Use four - 1/2" x 1 1/2" bolt to install mounting bracket. You will use three bolts from the sides and one from the bottom of the frame. Do the same for the other side.
5. Tighten the bottom bolt first then the sides.
6. Mount the grill guard by using four carriage bolts, two on each side. Slide the uprights of the grill guard to the outside of the mounting bracket. Put the carriage bolt through the upright and then the mounting bracket.
7. Level the grill guard and then tighten nuts.
8. **MAKE SURE ALL NUTS AND BOLTS ARE TIGHT!**

**----- WARNING -----**

Special care should be exercised in the handling, storage and installation of Kaspar Ranch Hand equipment.

The actual weight of each piece of equipment will vary depending on style and model. The weight of the equipment is sufficient in volume to warrant special care, assistance and in some instances, the use of mechanical equipment during the transfer and installation of the equipment.

Do not assume a position directly under the equipment during installation. Be sure the equipment has been connected and stabilized during installation to prevent falling or shifting of positions.

Periodically check tightness of bolts to make sure they are tight, and unlikely to fail.

Rev. 2/5/15