



STEP 1 – PRIOR TO INSTALLATION

- A) Husky®** only approves installing the flares according to these written instructions with the hardware provided. **WARNING:** Failure to install according to these instructions will invalidate the warranty. This includes, but is not limited to using alternative installation methods, hardware, or materials. **DO NOT USE:** Loctite, SuperGlue, or similar products on the hardware or the flares.
- B) Fit:** Verify the fit of the flares to vehicle. (Some filing, sanding, or cutting may be necessary to ensure proper fit).
- C) Painting:** (Optional) if paint is desired it must be done prior to installing flares on vehicle. Clean outer surface with a good grade degreaser. **DO NOT USE LACQUER THINNER OR ENAMEL REDUCER AS A DEGREASER.** Wipe outer surface thoroughly with a tack rag prior to paint. Application of plastic adhesion promoter for ABS plastic as per your paint system manufacturer's recommendations is required. Paint flares using a high quality enamel, or polyurethane automotive paint. If painting edge trim (not recommended), use a flex additive.
- D) Performance:** Using larger Tires may increase the area required to turn the vehicle. Some Tire/Rim combinations may require lowering bump stops and or installing steering stops to prevent tire from contacting flare.
- E) Exhaust System:** Modifications may be necessary to maintain a minimum 4" clearance between flares and exhaust pipes. (Exhaust gases should not vent directly onto flares)
- F) Metal Protection:** All exposed fasteners and bare metal should be treated with rust resistant paint **BEFORE** installing flares. Spray inner fender wells with undercoating **AFTER** flare attachments have been completed.
- G) Decals:** Flares may interfere with existing decals on vehicle. If you wish, remove decals prior to installation of flares.
- H) Care & Cleaning:** Husky fender flares are built to last; any detergent you use to wash your vehicle is sufficient to clean the flare. Do not use any harsh abrasive detergents.

Ford Fender Flares Set of 4

Set Part #2802975
#2802976
#2802977

Rev-0 03/10/2023

TOOLS FOR EASY INSTALLATION:

- Utility Knife
- #2 Phillips Screwdriver
- Fastener Removal Tool
- Grease Pencil
- Socket Set

PLEASE READ: Dirt and debris can become lodged between the fender flares and the vehicle's fenders, causing scratching and paint wear from vibration. Husky Liners is not responsible for any damage, and the installation of our fender flares is done with the buyer's understanding that this scratching and paint wear may occur.

3 YEAR LIMITED WARRANTY AGAINST ANY MANUFACTURING DEFECTS

- To claim a warranty, you must provide Proof of Purchase.



The material that your product is made from can be recycled. Please also consider recycling the packaging that your product came in.



Included in Hardware Kit:

- | | | | | | | |
|---|--|--|---|--|--|---|
| 1.

SW1-0067,
5/16 x 18 x 3/8"
SS Torx Screw,
(Pocket Style Only)
24 pcs | 2.

WA1-0012,
.320 x.700 x.03
SS Washer,
(Pocket Style Only)
24 pcs | 3.

NU1-0019,
5/16-18 Jam Fin.
Nylock Nut,
(Pocket Style Only)
24 pcs | 4.

SW1-0052,
T-45 Torx Bit,
(Pocket Style Only)
1 pc | 5.

RV1-P018,
8 x 20mm Black
Nylon Retainer,
22 pcs | 6.

RV1-P009,
8x15x20mm
Retainer,
4 pc | 7.

ET1-0002,
Edge Trim Tool,
1 pc |
| 8.

GP1-0025
Edge Trim
338 in. | 9.

CL1-0001,
.185-.225
SS "U" Clip,
6 pc | | | | | |

Component List:



New Images

If your flares already have the edge trim and pocket hardware installed, skip to Front Flare Installation Step 4.

STEP 2 - EDGE TRIM INSTALLATION

A. Peel two to three inches of red vinyl backing away from Edge Trim (GP1-0025) tape. Applying the adhesive side of the edge trim to the inner side of the flare, affix the edge trim to the top edge of the flare (the portion that comes in contact with the vehicle).

B. Press edge trim into place along the top edge of the flare in one-foot increments, pulling red vinyl backing free as you continue to work your way around the top edge of the flare.



Front Flare Installation Procedures (Drivers's Side):




Remove (10) factory installed fasteners.

NOTE: (3) fasteners marked with (*) will be reused in flare installation.



Pull factory wheel arch molding away from fender.

Front Flare Installation Procedures (Drivers's Side):




Depress tabs and disconnect light plug. Remove parking lamp.




Press in lamp while off vehicle.



Push factory wheel arch molding back into place. Reinstall (3) factory fasteners.




Reconnect parking lamp. Install (2) RV1-0009 fasteners and (5) RV1-P018 fasteners in remaining holes.




Installation complete.

Rear Flare Installation Procedures (Driver's Side):




If vehicle is equipped with factory bed step, use this configuration for rear fender flare.

NOTE: Flare will be marked W/ STEP



If vehicle is NOT equipped with factory bed step, use this configuration for rear fender flare.

NOTE: Flare will be marked NO STEP



Connect the rear flare piece you have determined that is needed from step 8 or 9 with (3) CL1-0001 Clips.



Remove (2) factory installed fasteners for forward rock guard, and (3) factory installed fasteners for deflector. Rock guard and deflector may be discarded.



Remove (6) factory installed fasteners and (1) screw.

NOTE: (1) Screw marked with (*) will be reused in flare installation.



Align fender flare with holes and position on fender.



Install (6) RV1-P018 fasteners.



Reinstall (1) factory screw.



Installation complete.

Edge Trim Tool Procedures:



Using supplied Edge Trim Tool (ET1-0002), seat edge trim against vehicle by hooking curved end under edge trim at one end of flare. Next, slide around outer edge of flare to the other end.



Using flat end of supplied Edge Trim Tool (ET1-0002), seat edge trim against flare by inserting straight end between edge trim and flare at one end. Next, slide around entire edge to the other end.