



Marker Light and Wiring Components


1.




Marker Light
2.




Butt Connector
3.




Posi-Tap
Connector
4.




Marker Light
Lens Cover
5.




Butt Connector
6.




Marker Light
Gasket
7.




Washer
8.




Screw
9.



Wire Stay
10.



Connection
Wire (30 ft)
11.



R98022
ALCOHOL PREP
PAD,

Components and Hardware:

1. Marker Light.....	(4)
2. Butt Connector.....	(8)
3. Posi-Tap Connector	(8)
4. Marker Light Lens Cover	(5)
5. Blackout Film	(4)
6. Gasket	(4)
7. Washer	(8)
8. Screw.....	(8)
9. Wire Stay	(8)
10. Connection Wire	(30 ft.)
11. Alcohol Prep Pad	(2)

Tools for Installation:

- Utility Knife
- #2 Phillips Screwdriver
- Wire Crimp Tool

Fender Flare Components and Hardware:

1. 
CL1-0009,
Long "U" Clip,
Magni 565
2. 
SW1-0058,
#10 x 5/8" Phillips
SS Truss Screw,
3. 
MT1-0014,
1" x 1.5" x .01"
Black Mylar Tab,
4. 
RV1-P018,
8 x 20mm Black
Nylon Retainer,
5. 
GP1-0025,
EX4008 Wiper
Style Edge Trim,
6. 
ET1-0002,
Edge Trim Tool,
7. 
CL1-0001,
.185-.225
SS "U" Clip,
8. 
Front Fender Flare
9. 
Rear Fender Flare
10. 
Rear Fender Flare
Extension

Components and Hardware:

1. Long "U" Clip Magni 565..... (4)
2. #10 x 5/8" Phillips SS Truss Screw..... (4)
3. 1" x 1.5" x 0.1" Black Mylar Tab (4)
4. 8 x 20mm Black Nylon Retainer (22)
5. Wiper Style Edge Trim..... (338")
6. Edge Trim Tool..... (1)
7. .185 - .225 SS "U" Clip (6)
8. Front Fender Flare (LH & RH)..... (2)
9. Rear Fender Flare (LH & RH)..... (2)
10. Rear Fender Extension (LH & RH)..... (4)

Tools for Installation:

- Utility Knife
- #2 Phillips Screwdriver
- Socket Wrench
- 10mm Socket
- Awl or Similar Pointed Tool
- Grease Pencil
- Pliers

Ford Fender Flares

PRIOR TO INSTALLATION

1

- A. Husky® only approves installing the flares according to these written instructions with the hardware provided. **WARNING:** Failure to install according to these instructions will invalidate the warranty. This includes, but is not limited to using alternative installation methods, hardware, or materials. **DO NOT USE:** Loctite, SuperGlue, or similar products on the hardware or the flares.
- B. **Fit:** Verify the fit of the flares to vehicle. (Some filing, sanding, or cutting may be necessary to ensure proper fit).
- C. **Painting:** (Optional) if paint is desired it must be done prior to installing flares on vehicle. Clean outer surface with a good grade degreaser. **DO NOT USE LACQUER THINNER OR ENAMEL REDUCER AS A DEGREASER.** Wipe outer surface thoroughly with a tack rag prior to paint. Application of plastic adhesion promoter for ABS plastic as per your paint system manufacturer's recommendations is required. Paint flares using a high quality enamel, or polyurethane automotive paint. If painting edge trim (not recommended), use a flex additive.
- D. **Performance:** Using larger Tires may increase the area required to turn the vehicle. Some Tire/Rim combinations may require lowering bump stops and or installing steering stops to prevent tire from contacting flare.
- E. **Exhaust System:** Modifications may be necessary to maintain a minimum 4" clearance between flares and exhaust pipes. (Exhaust gases should not vent directly onto flares)
- F. **Metal Protection:** All exposed fasteners and bare metal should be treated with rust resistant paint **BEFORE** installing flares. Spray inner fender wells with undercoating **AFTER** flare attachments have been completed.
- G. **Decals:** Flares may interfere with existing decals on vehicle. If you wish, remove decals prior to installation of flares.
- H. **Care & Cleaning:** Husky® fender flares are built to last; any detergent you use to wash your vehicle is sufficient to clean the flare. Do not use any harsh abrasive detergents.

PLEASE READ: Dirt and debris can become lodged between the fender flares and the vehicle's fenders, causing scratching and paint wear from vibration. Husky® is not responsible for any damage, and the installation of our fender flares is done with the buyer's understanding that this scratching and paint wear may occur.

3 YEAR LIMITED WARRANTY AGAINST ANY MANUFACTURING DEFECTS


- To claim a warranty, you must provide Proof of Purchase.

Ford Fender Flares

Light Assembly Installation

2

- A) Clean the top surface of the cover (indicated by blue arrow) with the alcohol pad.
- B) Install the Blackout Film to the top surface Cover by first aligning the two dashed red edges as shown.
- C) Assemble Light assembly to fender flare as shown. Route marker light wire through the center hole in the gasket and fender flare. **DO NOT** overtighten screws as this could crack the cover. Tighten enough that the light assembly does not move.



Ford Fender Flares

Edge Trim Installation


3

- A)** Peel two to three inches of red vinyl backing away from Edge Trim tape. Applying the adhesive side of the edge trim to the inner side of the flare, affix the edge trim to the top edge of the flare (the portion that comes in contact with the vehicle).
- B)** Press edge trim into place along the top edge of the flare in one-foot increments, pulling red vinyl backing free as you continue to work your way around the top edge of the flare.



Marker Light Wiring Detail

4



Ford Fender Flares

Front Flare Installation Procedures (Passenger's Side):

5

***Reference Step 4 Image**

- A) Find and access the wiring harness for your front or rear marker light. *Note that the marker light is often integrated into the headlight and taillight assemblies.
- B) Using two Posi-Tap connectors and the connection wire, connect the red lead to the marker light feed and the brown lead to a ground.
- C) Route the connection wire to the top center of the fender area. Use Wire Stays as appropriate to help manage wires.
- D) Cut the connection wire, leaving 1 foot of extra wire extended down from the top center of the fender area.
- E) Repeat Steps A-D at the other three flare locations.



6

Remove (5) factory installed fasteners.



7

Hold flare up and mark (2) flare positions with grease pencil.



Ford Fender Flares

8

Install supplied Black Foam Tab over the locations marked in Step 7. Install a Long "U" Clip Magni 565 as indicated on top of the protective film.



9


A) Before final install of the flare, connect the marker light to the connection wire using two Butt Connectors. Connect black to red and white to brown. Reference Step 4 image.

B) Properly heat shrink the connection.



10

Reconnect parking lamp. Install (2) SW1-0058 fasteners and (5) RV1-P018 fasteners in remaining holes.



Ford Fender Flares

11

Tuck the exposed wiring up between the lower flange of the flare and the fender so that no wiring is exposed. Use Wire Stays as appropriate to help manage wires.

Completed front flare installation.



Ford Fender Flares

12

Rear Flare Installation Procedures (Passenger's Side)

If vehicle is equipped with factory bed step, use this configuration for rear fender flare.

NOTE: Flare will be marked W/ STEP



13


If vehicle is NOT equipped with factory bed step, use this configuration for rear fender flare.

NOTE: Flare will be marked NO STEP



14


Connect the rear flare piece you have determined that is needed from step 8 or 9 with (3) CL1-0001 Clips.



Ford Fender Flares

15

Remove (2) factory installed fasteners for forward rock guard, and (3) factory installed fasteners for deflector. Rock guard and deflector may be discarded.



16

Remove (6) factory installed fasteners and (1) screw.

NOTE: (1) Screw marked with (*) will be reused in flare installation.



17

A) Before final install of the flare, connect the marker light to the connection wire using two Butt Connectors. Connect black to red and white to brown. Reference Step 4 image.

B) Properly heat shrink the connection.

Align fender flare with holes and position on fender.



Ford Fender Flares

18

Install (6) RV1-P018 fasteners.



19

Reinstall (1) factory screw.



20

Tuck the exposed wiring up between the lower flange of the flare and the fender so that no wiring is exposed. Use Wire Stays as appropriate to help manage wires.

Installation complete.



Ford Fender Flares

21

Using supplied Edge Trim Tool, seat edge trim against vehicle by hooking curved end under edge trim at one end of flare. Next, slide around outer edge of flare to the other end.



22

Using flat end of supplied Edge Trim Tool, seat edge trim against flare by inserting straight end between edge trim and flare at one end. Next, slide around entire edge to the other end.



Care and Cleaning

- Wash only with mild soap & dry with a clean cloth.



The material that your product is made from can be recycled. Please also consider recycling the packaging that your product came in.

Congratulations!

We take the utmost pride in our products and want you to enjoy years of satisfaction from your investment. We have made every effort to ensure that your product is top quality in terms of fit, durability, finish and ease of installation.

www.huskyliners.com

Phone: 800-344-8759

Email: customerservice@huskyliners.com

