














Fender Flare Components and Hardware:

- | | | | |
|---|---|---|---|
| <p>1. 
MT1-0014,
1" x1.5" x.01"
Black Mylar Tab,</p> | <p>2. 
CL1-0005,
Dacromet "S"
Spring Clip,</p> | <p>3. 
RV1-P009,
8x15x20mm
Retainer,</p> | <p>4. 
SW1-0058,
#10 x 5/8" Phillips
SS Truss Screw,</p> |
| <p>5. 
SW1-0050,
10 x 5/16 Phillips
Truss Screw,</p> | <p>6. 
MT1-0034,
1" x1.5" x.06"
Blk 3M Foam Tab,</p> | <p>7. 
CL1-0009,
Long "U" Clip,
Magni 565</p> | <p>8. 
CL1-0001,
.185-.225
SS "U" Clip,</p> |
| <p>9. 
ET1-0002,
Edge Trim Tool,</p> | <p>10. 
GP1-0025,
EX4008 Wiper
Style Edge Trim,</p> | <p>11. 
Front Fender Flare</p> | <p>12. 
Rear Fender Flare</p> |
| <p>13. 
Front Fender Flare
Bracket</p> | | | |

Components and Hardware:

1. Black Mylar Tab	(4)
2. Dacromet "S" Spring Clip.....	(4)
3. Retainer	(10)
4. #10 x 5/8" Phillips SS Truss Screw.....	(8)
5. 10 x 5/16 Phillips Truss Screw.....	(4)
6. Black 3M Foam Tape	(4)
7. Long "U" Clip	(4)
8. .185-.225 SS "U" Clip	(6)
9. Edge Trim Tool.....	(1)
10. Wiper Style Edge Trim.....	(336")
11. Front Fender Flare.....	(2)
12. Rear Fender Flare	(2)
13. Bracket	(2)

Tools for Installation:

- #2 Phillips Screwdriver
- Socket Wrench
- 10mm Socket
- Awl or Similar Pointed Tool
- Grease Pencil

Fender Flares

PRIOR TO INSTALLATION

1

- A. Husky® only approves installing the flares according to these written instructions with the hardware provided. **WARNING:** Failure to install according to these instructions will invalidate the warranty. This includes, but is not limited to using alternative installation methods, hardware, or materials. **DO NOT USE:** Loctite, SuperGlue, or similar products on the hardware or the flares.
- B. **Fit:** Verify the fit of the flares to vehicle. (Some filing, sanding, or cutting may be necessary to ensure proper fit).
- C. **Painting:** (Optional) if paint is desired it must be done prior to installing flares on vehicle. Clean outer surface with a good grade degreaser. **DO NOT USE LACQUER THINNER OR ENAMEL REDUCER AS A DEGREASER.** Wipe outer surface thoroughly with a tack rag prior to paint. Application of plastic adhesion promoter for ABS plastic as per your paint system manufacturer's recommendations is required. Paint flares using a high quality enamel, or polyurethane automotive paint. If painting edge trim (not recommended), use a flex additive.
- D. **Performance:** Using larger Tires may increase the area required to turn the vehicle. Some Tire/Rim combinations may require lowering bump stops and or installing steering stops to prevent tire from contacting flare.
- E. **Exhaust System:** Modifications may be necessary to maintain a minimum 4" clearance between flares and exhaust pipes. (Exhaust gases should not vent directly onto flares)
- F. **Metal Protection:** All exposed fasteners and bare metal should be treated with rust resistant paint **BEFORE** installing flares. Spray inner fender wells with undercoating **AFTER** flare attachments have been completed.
- G. **Decals:** Flares may interfere with existing decals on vehicle. If you wish, remove decals prior to installation of flares.
- H. **Care & Cleaning:** Husky® fender flares are built to last; any detergent you use to wash your vehicle is sufficient to clean the flare. Do not use any harsh abrasive detergents.

PLEASE READ: Dirt and debris can become lodged between the fender flares and the vehicle's fenders, causing scratching and paint wear from vibration. Husky® is not responsible for any damage, and the installation of our fender flares is done with the buyer's understanding that this scratching and paint wear may occur.

3 YEAR LIMITED WARRANTY AGAINST ANY MANUFACTURING DEFECTS


- To claim a warranty, you must provide Proof of Purchase.

Fender Flares

Front Flare Installation Procedures (Passenger's Side):


1

Connect the front flare piece with (3) CL1-0001 Clips.



2

Remove and retain (4) screws from factory mudflap. Discard mudflap.




3

Remove (2) plastic fasteners from top of wheel well and discard.




Fender Flares


4 Position flare on vehicle, and mark (2) front locations.



5 Install 2 Black Mylar Tabs (MT1-0014) and (2) Dacromet "S" Spring Clips (CL1-0005) at locations marked in **Step 4**.



6 Install inner bracket using (2) RV1-P009 fasteners.




Fender Flares

7

Align fender flare in place on fender.

Reinstall (3) factory screws in holes where mudflap was originally. Install (2) SW1-0058 fasteners at the top of the flare, and (2) SW1-0050 fasteners toward the front of the flare.



8

Completed front flare installation.



9

Rear Flare Installation Procedures (Passenger's Side):

Remove and retain (4) screws from factory mudflap. Discard mudflap.



Fender Flares

10 Remove (3) plastic fasteners.



11 Hold flare and mark (2) locations.



12 Install (2) MT1-0034 and CL1-0009.




Fender Flares

13

Align fender flare in place on fender.

Reinstall (3) factory screws in holes where mudflap was originally. Install (2) SW1-0058 fasteners at the top of the flare, and (3) RV1-P009 fasteners toward the front of the flare.



Care and Cleaning

- Wash only with mild soap & dry with a clean cloth.



The material that your product is made from can be recycled. Please also consider recycling the packaging that your product came in.

Congratulations!

We take the utmost pride in our products and want you to enjoy years of satisfaction from your investment. We have made every effort to ensure that your product is top quality in terms of fit, durability, finish and ease of installation.

www.huskyliners.com

Phone: 800-344-8759

Email: customerservice@huskyliners.com

