


07-UP JEEP JK HD FORGED ADJUSTABLE REAR TRACK BAR 0-6" LIFT

raptorseries
OFFROAD & PERFORMANCE

COMPONENTS:



Adjustable
Rear Track Bar 0-6" Lift
Qty 1

TOOLS REQUIRED:

- 21MM Socket/Wrench
- 21MM Open-End Wrench
- 1-1/2" Open-End Wrench
- Torque Wrench
- Tape Measure
- Heavy Duty Ratchet Strap
- Anti-Seize Lubricant
- Factory Service Manual

Safety Warning:

Aftermarket suspension systems or components may cause your vehicle to handle differently than it would with factory components. Please use caution to prevent loss of control or vehicle rollover during quick sharp turns and other sudden maneuvers. Thoroughly inspect vehicle suspension and components before and after every off-road use.

Raptor Series Off-Road recommends the use of your Factory Service Manual for disassembly and assembly of factory and related components. Tighten all bolts and hardware to factory torque specifications unless otherwise specified in this instruction.

INSTRUCTIONS:

1. Remove Rear Track Bar

Using a 21MM Socket/Wrench, remove the bolt connecting the rear track bar to the axle mount.

Next, using a 21MM Socket/Wrench and a 21MM Open-End Wrench, remove the bolt connecting the rear track bar to the vehicle chassis.

Save original hardware to be used for installation.

Once both bolts have been removed, you may remove the original track bar from the vehicle.

2. Center Rear Axle

Determine if the axle housing is centered with the chassis by measuring the distance between the tires and chassis, using the same points on each side of the vehicle to ensure accuracy.

If the two measurements are the same, the axle is centered. If the two measurements are different, divide the difference in half to determine the amount of required adjustment. The chassis can be shifted using either of the following methods.

Ratchet Strap:

- Attach a heavy duty ratchet strap to the chassis on one side of the vehicle, and to the axle housing on the other side.
- Tighten the strap in small increments to pull the chassis in alignment with the axle.
- Take measurements after each adjustment until centered.

Steering Wheel:

- Have a partner turn the steering wheel in small increments to shift the vehicle chassis side-to-side.
- After each adjustment, have your partner hold the steering wheel steady while you take measurements.

3. Install Rear Track Bar

Apply anti-seize lubricant to bolt threads of original track bar mounting hardware as well as the adjustment threads of the track bar.


With the axle centered beneath the chassis, loosely attach the track bar to the chassis side using factory hardware. (3a)

Turn the adjusting shaft until the sleeve in the rubber bushing aligns with the mounting hole on the axle mount, then loosely attach the track bar to the axle mount using factory hardware. (3b)

To center the axle under the Jeep, use a 15mm socket to loosen the adjustment sleeve clamps (3c) and turn the sleeve (3d). When adjustment is finalized, torque bolts to 45 ft-lbs.

Once all adjustments have been completed, tighten the jam nut using a 1-1/2" Open-End Wrench. It may be easier to tighten the jam nut with the track bar removed from the vehicle.

Using a torque wrench, tighten the factory track bar bolts at both ends of the track bar to 125 ft-lbs.



4. Post Installation

It is necessary to have a professional wheel alignment performed by a certified technician to ensure the vehicle is aligned to factory specifications.

Upon completion of installation and within 50 miles of driving, it is necessary to check and ensure all hardware is properly torqued to factory specifications as noted in the factory service manual or as specified in this instruction.