




IAT-92210 2018-Current Jeep Wrangler JL & JT


Component List:




1. Truck Mount Bracket	(8)
2. Board Mount Bracket	(8)
3. Carriage Bolt M10 x 25mm	(16)
4. Serrated Flange Nut M10	(16)
5. Flange Bolt M8 x 30mm	(24)
6. Serrated Flange Nut M8	(16)
7. Flange Bolt M6 x 25mm	(2)
8. Serrated Flange Nut M6	(2)
9. Hex Bolt 5/16" - 18 x 1"	(16)
10. Serrated Flange Nut 5/16" - 18	(16)

Note: JL (Wrangler) models will use 3 brackets per side and JT (Gladiator) will use 4 brackets per side.


Installation Instructions:



STEP 1:
When placing truck bracket (1) in the furthest forward position notice this hole in the bracket. This hole is to accommodate the OE plastic pin to fit through. This pin is found on the back of the pinch weld.




STEP 2:
Use M8 flange bolt (5) through the truck bracket (1) into the threaded hole under the Jeep body. Just hand tighten at this time.



STEP 3:
Use M8 flange bolt (5) through the pinch weld of the Jeep then through truck bracket (1) and secure with serrated flange nut (6).

Note: In some applications there is a smaller hole in the pinch weld of the first bracket location. If your model has this use the provided M6 bolt (7) and nut (8) instead of the M8 nut and bolt.


IAT-92210 2018-Current Jeep Wrangler JL & JT



STEP 4:

Before installing the board bracket (4), decide the preferred height. Here are our suggestions, but you can adjust to your preference:

- A. For 61 Series, 51 Series, & Gladiator boards.
- B. For 41 Series, CVX, & Factory Style boards (all from A).
- C. Lower position for any board.



STEP 5:

Use a carriage bolt (3) through the truck bracket (1) into the board bracket (2) and secure it with a serrated flange nut (4). Hand-tighten at this time.

STEP 6:

With one side of the brackets installed, use a flat edge (such as a yardstick, level, or the included running board) placed on the board bracket tab. Align the brackets level to each other and fully tighten all hardware.



STEP 7:

To install running boards onto the brackets, obtain the board bolt pack included with the board you selected. Take the 5/16" X 1" long bolts, and slide the head of the bolts down the channels on the underside of the board. Use 3-JL, or 4-JT bolts in both channels.



STEP 8:

Place the board on the installed mounting brackets. Align the bolts with the slots on the brackets and drop them into place. Thread the provided 5/16" flange nuts onto the bolts, but do not fully tighten yet. Adjust the board left to right and in and out to your desired position. Avoid using power or air tools. Finally, tighten all board hardware to 20ft lbs torque to secure the board to the bracket.