
Installation Manual



Warnings:

- Please follow the installation instructions carefully, failure to do so will cause property loss or road accidents!
- We are not responsible for damages to your vehicle if the load is above the weight limits.
 Consult your vehicle owner's manual for any weight or load restrictions.
- This kayak rack can be only installed on vehicles with cross roof bars.

Contents:



Installation Steps:





1.install rear wheel cradle

2. openg the cover of the head unit






3.Place the carrier onto the crossbar in proper position
Use 4* carriage bolt and 2* metal bracket to install the head unit on the front crossbar



4. Slide 4 T-bolt M8X45mm into the channels under the aluminum bar, and use 2* metal bracket to tight the rear part on the rear crossbar.

Installation Steps(T-slot installation):



STEP 1:

Assemble the front bike mount under the head unit by button head bolt and tight.

Slide two T-bolt M8X16mm into the slot of the bike aluminum spine and tight the rear bike mount under the aluminum spine in proper position as shown.



STEP 2:

Slide the T-bolt M8X16mm into the T-slot of the cross bar in proper position, two bolts in each bar. and put the bike rack on the cross bar and tighten the lock nut as shown.



Install the bike onto the Rack:





Place bike on the carrier, adjust the grip arm and secure the bike



Note: loose the screw to adjust the position of rear wheel cradel according to the bike size