



INSTALLATION INSTRUCTIONS

Console Safe #393-01

2022 – Current Chevrolet Silverado & GMC Sierra

Fits Vehicles with Wireless Charging Pad Console


See tuffyprompts.com for Fitment Guide

QC CHECK

- ____ SHIP PACK CONTENTS
- ____ VISUAL INSPECTION
- ____ LOCK FUNCTION TEST
- ____ RUBBER SEAL
- ____ SHIPPING PACKAGE
- ____ PLATE BUNDLE

Please read and fill out the enclosed warranty registration card or register online at <https://tuffyprompts.com/help/warranty-information/warranty-registration/> to activate your warranty.

PARTS CHECKLIST



SHIPPING PACKAGE CHECKLIST



TOOLS CHECKLIST

- 5/32" Hex Wrench
- 7/16" End Wrench
- 10mm Socket
- Phillips Head Screwdriver
- 4mm Hex Wrench

PLEASE READ ALL INSTRUCTIONS THOROUGHLY BEFORE STARTING INSTALLATION.

1. Remove all contents from the shipping box and confirm that you have all the components listed above.
2. Invert the #393 Console Insert so it rests on its lid, expand the legs and assemble the lid support hardware as shown in **Figure 1**.

Tighten the hardware in small increments so that the lid remains supported as you require (*usually self-supporting at a 45-degree lid angle*).

NOTE: One of the #1.1.2 Nylon Washers (shown to the left of the slotted arm) slips between the slotted arm and the stationary frame.

NOTE: Over time, the friction that holds the lid in the open position may be reduced. To increase the friction, it is necessary to tighten the assembly. Tighten in small increments as required, removal of the Console Insert should not be necessary.




FIGURE 1

- Lower the #1.2 Fill Plate into place at the rear of the Console Insert and secure in place using (3) #1.3 Screws. Start the screws by hand to insure they do not become cross-threaded. **See Figure 2.**
NOTE: A small-shaft screwdriver or awl may be used to align the holes in the Console Insert and the #1.2 Fill Plate.




FIGURE 2

- Remove the contents of the factory console, including the bottom mat.
- Remove the two factory console mounting bolts from the bottom of the console. They will not be re-used, but should be set aside if you wish to return the console to factory condition.
- Pull out the two Hanging Folder Supports straight out and set aside. you may use a plastic trim tool, but this step can be completed by hand. **See Figure 3.**




FIGURE 3

- With the back leg extended and the front leg bent, angle the console safe so the edge is under the plastic extrusions and place it gently down into the console. You may want to grip it with the lid open. **See Figure 4**




FIGURE 4

(Some Parts not Shown for Clarity)

8. Fold the legs out completely and place the #1.5 Bottom Plates on the legs so the holes line up with the mounting holes.
9. Insert the (4) #1.4 Screws through the holes in the #1.5 bottom Plates and into the base of the console.

See Figure 5.

NOTE: Do not overtighten hardware, stop tightening once the #1.2 Bottom Plates begin to deflect into the cavity.




FIGURE 5

10. Insert the #1.6 Screws through the bottom plates into the base of the console. **See Figure 6**
11. Reinstall the Rubber Mat to the bottom of the console over the mounting hardware along with the other contents.
12. Reinstall the Hanging Folder Supports by pushing them straight back in.




FIGURE 6